Original		Replacement	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
MUTE	Mute	MUTE	Mute
MODE	Mode	APP MEDIA	Media
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
+/--		SHIFT + -/-- GUIDE	Shift + Guide
BACK	Back	RETURN BACK	Back
NICAM/A2	Nicam/A2	SOUND DUAL	Dual

Original		Replacement	
TXT/MIX	TXT/MIX	REPEAT TEXT	Text
TXT/MIX	Play	PLAY MODE	Play
TXT/MIX	Pause		Pause
CANCEL	Stop		Stop
REC	Rec	REC MODE	Rec
INDEX	>>/Index		>>
HOLD	<<</Hold		<<
SIZE	I <<		I <<
REVEAL	>>I		>>I
CANCEL	Cancel	CLEAR EXIT	Exit
MENU	Menu	TOP MENU MENU	Menu
DTV/RADIO	DTV/Radio	SEARCH TV/R	TV/R
VOL+	Vol +	+ VOL	Vol +
VOL-	Vol -	VOL -	Vol -
	Up		Up
	Down		Down
	Right		Right

Original	Replacement
Left	Left
Enter	Ok
CH+	Ch +
CH-	Ch -
FAV	Pre Ch
EPG	Guide
Info	Info
List	List
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
Size	Format
Reveal	3D
Subtitle	Subt
Subpage	AV
FAV+	Shift + Ch +

Original	Replacement
FAV-	Shift + Ch -

Original	Replacement	Original	Replacement
Power	Power	Vol +	Vol +
Mute	Mute	Vol -	Vol -
[I] / Menu	Menu	CH+	Ch +
Exit	Exit	CH-	Ch -
Source	AV	Up	Up
1	1	Down	Down
2	2	Right	Right
3	3	Left	Left
4	4	OK	Ok
5	5	Recall	Back
6	6	Info	Info
7	7	EPG	Guide
8	8	Freeze	Options
9	9	Red	Red
0	0	Green	Green
Subtitle	Subt	Yellow	Yellow
Text	Text	Blue	Blue

Original	Replacement		Original	Replacement
Audi o	SOUND DUAL	Dual		
I <</ [≡+]		I <<		
>>I / [≡ .]		>>I		
[≡i]	HOME SMART	Smart		
Pl ay	PLAY MODE ▶	Pl ay		
Pause		Pause		
St op		St op		
REP/ Rec	REC MODE	Rec		
<</ [≡o]		<<		
>>/ [≡?]		>>		
FAV	FAV PRE-CH	Pre Ch		