Original		Replacement	
	Power Tv		Power
	Av Tv	TIMER AV	AV
MENU	Menu Tv	TOP MENU MENU	Menu
	Up Tv		Up
	Down Tv		Down
	Left Tv		Left
	Right Tv		Right
OK	Ok Tv	OK	Ok
INFO	Info Tv	DISPLAY INFO	Info
EXIT	Exit Tv	CLEAR EXIT	Exit
	Red Tv	A	Red
	Green Tv	B	Green
	Yellow Tv	C	Yellow
	Blue Tv	D	Blue
+ VOL	Vol + Tv	+ VOL	Vol +
VOL −	Vol - Tv	VOL −	Vol -
	Mute Tv	MUTE	Mute

Original		Replacement	
P•P	Back Tv	RETURN BACK	Back
+ CH	Ch+ Tv	+ CH	Ch +
CH −	Ch- Tv	CH −	Ch -
▼P[≡]	▼P[≡] Tv		I <<
▲P[ ]	▲P[ ] Tv		>>I
	<< Tv		<<
	>> Tv		>>
	Stop Tv		Stop
	Play Tv	PLAY MODE	Play
1	1 Tv	1	1
2	2 Tv	2	2
3	3 Tv	3	3
4	4 Tv	4	4
5	5 Tv	5	5
6	6 Tv	6	6
7	7 Tv	7	7
8	8 Tv	8	8

Original	Replacement
9 Tv	9
0 Tv	0
Text Tv	Text
#Help Tv	Pre Ch
▼P [≡] Tv2	Shift + I <<
▲P [ ] Tv2	Shift + >>I
Rec Tv2	Shift + Rec
Play Tv2	Shift + Play
Av Tv2	Shift + AV
<< Tv2	Shift + <<
>> Tv2	Shift + >>
Power Tv2	Shift + Power
Guide Tv2	Shift + Guide
Menu Tv2	Shift + Menu
Up Tv2	Shift + Up
Left Tv2	Shift + Left
Right Tv2	Shift + Right

Original	Replacement
Down Tv2	Shift + Down
Ok Tv2	Shift + Ok
Info Tv2	Shift + Info
Green Tv2	Shift + Green
Red Tv2	Shift + Red
Exit Tv2	Shift + Exit
Yellow Tv2	Shift + Yellow
Blue Tv2	Shift + Blue
Back Tv2	Shift + Back
Ch+ Tv2	Shift + Ch +
Ch- Tv2	Shift + Ch -
Stop Tv2	Shift + Stop
Pause Tv2	Shift + Pause
1 Tv2	Shift + 1
2 Tv2	Shift + 2
3 Tv2	Shift + 3
4 Tv2	Shift + 4

Original		Replacement		Original	Replacement
5	5 Tv2	SHIFT + 5	Shift + 5		
6	6 Tv2	SHIFT + 6	Shift + 6		
7	7 Tv2	SHIFT + 7	Shift + 7		
8	8 Tv2	SHIFT + 8	Shift + 8		
9	9 Tv2	SHIFT + 9	Shift + 9		
0	0 Tv2	SHIFT + 0	Shift + 0		
* TXT	Text Tv2	SHIFT + REPEAT TEXT	Shift + Text		
# HELP	#Help Tv2	SHIFT + FAV PRE-CH	Shift + Pre Ch		

Original	Replacement	Original	Replacement
Power DVD	Power	Mute DVD/ DVR	Mute
AV DVD/ DVR	AV	Back DVD/ DVR	Back
Guide DVD/ DVR	Guide	Ch+ DVD/ DVR	Ch +
Menu DVD/ DVR	Menu	▼P[≡] DVD/ DVR	I <<
Info DVD/ DVR	Info	Ch- DVD/ DVR	Ch -
Exit DVD/ DVR	Exit	▲P[ ] DVD/ DVR	>>I
Up DVD/ DVR	Up	<< DVD/ DVR	<<
Down DVD/ DVR	Down	>> DVD/ DVR	>>
Left DVD/ DVR	Left	Play DVD/ DVR	Play
Right DVD/ DVR	Right	Pause DVD/ DVR	Pause
Ok DVD/ DVR	Ok	Stop DVD/ DVR	Stop
Red DVD/ DVR	Red	Rec DVD/ DVR	Rec
Green DVD/ DVR	Green	1 DVD/ DVR	1
Yellow	Yellow	2 DVD/ DVR	2
Blue DVD/ DVR	Blue	3 DVD/ DVR	3
Vol + DVD/ DVR	Vol +	4 DVD/ DVR	4
Vol - DVD/ DVR	Vol -	5 DVD/ DVR	5

Original		Replacement		Original	Replacement
6	6 DVD/ DVR	6	6		
7	7 DVD/ DVR	7	7		
8	8 DVD/ DVR	8	8		
9	9 DVD/ DVR	9	9		
0	0 DVD/ DVR	0	0		
* TXT	Text DVD/ DVR	REPEAT TEXT	Text		
# HELP	#Help DVD/ DVR	FAV PRE-CH	Pre Ch		
⏻	Power DVR	SHIFT + ⏻	Shift + Power		

Original	Replacement	Original	Replacement
Power	Power	Mute	Mute
Menu	Menu	Back	Back
Guide	Guide	Ch+ SAT/ CABLE	Ch +
AV SAT/ CABLE	AV	Ch- SAT/ CABLE	Ch -
Up SAT/ CABLE	Up	<< SAT/ CABLE	<<
Down	Down	>> SAT/ CABLE	>>
Left SAT/ CABLE	Left	Stop SAT/ CABLE	Stop
Right	Right	Rec SAT/ CABLE	Rec
Ok SAT/ CABLE	Ok	Play SAT/ CABLE	Play
Info SAT/ CABLE	Info	Pause	Pause
Exit SAT/ CABLE	Exit	1 SAT/ CABLE	1
Red SAT/ CABLE	Red	2 SAT/ CABLE	2
Green	Green	3 SAT/ CABLE	3
Yellow SAT/ CABLE	Yellow	4 SAT/ CABLE	4
Blue SAT/ CABLE	Blue	5 SAT/ CABLE	5
Vol +	Vol +	6 SAT/ CABLE	6
Vol - SAT/ CABLE	Vol -	7 SAT/ CABLE	7

Original		Replacement	
8	8 SAT/ CABLE	8	8
9	9 SAT/ CABLE	9	9
0	0 SAT/ CABLE	0	0
# HELP	#Help	FAV PRE-CH	Pre Ch
* TXT	Text SAT/ CABLE	REPEAT TEXT	Text

Original	Replacement

Original	Replacement	Original	Replacement
Power DVBT	Power	Ch+ DVBT	Ch +
Guide DVBT	Guide	Ch- DVBT	Ch -
Menu DVBT	Menu	Pause DVBT	Pause
Up DVBT	Up	1 DVBT	1
Down DVBT	Down	2 DVBT	2
Left DVBT	Left	3 DVBT	3
Right DVBT	Right	4 DVBT	4
Ok DVBT	Ok	5 DVBT	5
Info DVBT	Info	6 DVBT	6
Red DVBT	Red	7 DVBT	7
Green DVBT	Green	8 DVBT	8
Yellow DVBT	Yellow	9 DVBT	9
Blue DVBT	Blue	0 DVBT	0
Vol + DVBT	Vol +	Power VCR	Shift + Power
Vol - DVBT	Vol -	Av VCR	AV
Mute DVBT	Mute	<< VCR	<<
Back DVBT	Back	Stop VCR	Stop

Original	Replacement
>> VCR	>>
Play VCR	Play
Rec VCR	Rec
Pause VCR	Shift + Pause
Guide VCR	Shift + Guide
Menu VCR	Shift + Menu
Up VCR	Shift + Up
Down VCR	Shift + Down
Left VCR	Shift + Left
Right VCR	Shift + Right
Ok VCR	Shift + Ok
Info VCR	Shift + Info
Exit VCR	Exit
Red VCR	Shift + Red
Green VCR	Shift + Green
Yellow VCR	Shift + Yellow
Blue VCR	Shift + Blue

Original	Replacement
Back VCR	Shift + Back
Ch+ VCR	Shift + Ch +
Ch- VCR	Shift + Ch -
1 VCR	Shift + 1
2 VCR	Shift + 2
3 VCR	Shift + 3
4 VCR	Shift + 4
5 VCR	Shift + 5
6 VCR	Shift + 6
7 VCR	Shift + 7
8 VCR	Shift + 8
9 VCR	Shift + 9
0 VCR	Shift + 0
Text VCR	Text
#Help VCR	Pre Ch