Original		Replacement	
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
POWER	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
GOTO	Goto	GOTO TEXT	Text / Goto
0	0	HDMI - SAT 0	0
Clear	Clear	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
OSC	OSC	TITLE SOUND	Sound / Title
TOP MENU	Top Menu	TOP MENU D.MENU	D. Menu / Top
PIP	PIP	FORMAT PICTURE	Picture / Format

Original		Replacement	
POP UP/MENU	Pop Up/Menu	LIST SMART	Smart / List
REV	<<	TUNE-	<< / Tune-
PLAY/PAUSE	Play	SLOW	Play / Slow
PLAY/PAUSE	Pause	STEP - FREEZE	Pause / Step / Freeze
FWD	>>	TUNE+	>> / Tune+
SKIP	I <<	PRESET-	I << / Preset-
STOP	Stop	HOLD	Stop / Hold
SKIP	>>I	PRESET+	>>I / Preset+
HOME	Home	HOME MENU	Menu / Home
SETTING	Setting	OPT-TOOLS SETUP	Setup / OPT /
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
STEP/SLOW	Step/Slow	SHIFT + SLOW	Shift + Play /
STEP/SLOW	Step/Slow	SHIFT + STEP - FREEZE	Shift + Pause / Step /
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right

Original	Replacement	Original	Replacement
RETURN Return	RETURN BACK Back / Return		
Down	Down		
PROGRAM Red/ Program	NETFLIX SEARCH Red / Netflix / Search		
PROGRAM Red/ Program	PROGRAM TV/ RADIO TV/ Radio /		
DIGEST Green/ Digest	APP REPEAT Green / APP / Repeat		
ZOOM Yellow/ Zoom	YouTube REPEAT A-B Yellow / YouTube / Repeat		
ZOOM Yellow/ Zoom	SIZE ZOOM Zoom / Size		
BOOKMARK Blue/ Bookmark	Prime Video RANDOM Blue / Prime Video / Random		
SUB Sub	EQ SUBTITLE Subtitle / EQ		
AUDIO Audio	LANG I/II AUDIO Audio / Lang I/II		
2nd. AUDIO 2nd. Audio	SHIFT + LANG I/II AUDIO Shift + Audio / Lang I/II		
ANGLE Angle	ANGLE INFO Info / Angle		
A-B A-B	SHIFT + YouTube REPEAT A-B Shift + Yellow / YouTube /		
REPEAT Repeat	SHIFT + APP REPEAT Shift + Green / APP /		
DISPLAY Display	MEDIA DISPLAY Display / Media		