Original		Replacement	
Power		Power	
Mute		MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
-/--	-/--	SHIFT + -/-- GUIDE	Shift + Guide
Recall		FAV PRE-CH	Pre Ch
P.MODE	P.Mode	SHIFT + PICTURE FORMAT	Shift + Format
S.MODE	S.Mode	SHIFT + SOUND DUAL	Shift + Dual
NICAM	Nicam	SETTINGS OPT	Options

Original		Replacement	
SLEEP	Sleep	PROG SLEEP	Sleep
SOURCE	Source	TIMER AV	AV
CH +	CH+	CH +	Ch +
CH −	CH-	CH −	Ch -
VOL +	Vol+	VOL +	Vol +
VOL −	Vol-	VOL −	Vol -
INFO	Info	DISPLAY INFO	Info
MEDIA	Media	APP MEDIA	Media
FREEZE	Freeze	HOME SMART	Smart
ASPECT	Aspect	ECO 3D	3D
EPG	EPG	-/-- GUIDE	Guide
Up		Up	
Down		Down	
Right		Right	
Left		Left	
OK	OK	OK	Ok
MENU	Menu	TOP MENU MENU	Menu

Original		Replacement	
EXIT	Exit	CLEAR EXIT	Exit
TEXT ▶II	Text	REPEAT TEXT	Text
TEXT ▶II	Play	PLAY MODE ▶	Play
TEXT ▶II	Pause	II	Pause
HOLD ■	Stop/Hold	■	Stop
SIZE ◀◀	<<	«	<<
SIZE ◀◀	Size	PICTURE FORMAT	Format
REVEAL ▶▶	>>/Reveal	»	>>
INDEX ⏮	I<<Index	⏮	I<<
SUBPAGE ⏭	>>I/Subpage	⏭	>>I
LANG	Lang	SOUND DUAL	Dual
SUBTITLE	Subtitle	AD SUBT	Subt
REC	Rec	REC MODE ●	Rec
R.LIST	R.List	DISC NAV LIST	List
TV/RADIO	TV/Radio	SEARCH TV/R	TV/R
TIMESHIFT	Timeshift	RETURN BACK	Back
	Red	A	Red

Original		Replacement	
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue