Mandis shop

# Denon RC-270

| Original | | Replacement | |
|---|---|---|---|
| POWER | Power | | Power |
| PROG/DIRECT | Prog/Direct | PROG SLEEP | Sleep |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 10 | 10 | 0 | 0 |
| +10 | +10 | -/-- GUIDE | Guide |
| CALL | Call | FAV PRE-CH | Pre Ch |
| PLAY | Play | PLAY MODE | Play |
| PAUSE | Pause | | Pause |
| STOP | Stop | | Stop |

| Original | | Replacement | |
|---|---|---|---|
| REC | Rec | REC MODE | Rec |
| >>I | >>I | | >>I |
| I<< | I<< | | I<< |
| >> | >> | | >> |
| << | << | | << |
| TIME | Time | TIMER AV | AV |
| CLEAR | Clear | CLEAR EXIT | Exit |
| ENTER | Enter | OK | Ok |
| TITLE | Title | DISPLAY INFO | Info |
| CHARACTER | Character | SETTINGS OPT | Options |
| EDIT | Edit | SEARCH TV/R | TV/R |
| REPEAT 1/ALL | Repeat 1/ALL | REPEAT TEXT | Text |
| REPEAT A-B | Repeat A-B | E-MANUAL D.MENU | D. Menu |
| RANDOM | Random | APP MEDIA | Media |
| EJECT | Eject | ZOOM | Eject |
| MEMORY REC | Memory Rec | PICTURE FORMAT | Format |
| SYNCHRO REC | Synchro Rec | ECO 3D | 3D |

https://telecommandes-mandis.be/en/Denon/1056900-86420-replacement-remote-control-for-Denon-RC-270-00D3990473003.html