Original		Replacement	
POWER	Power		Power
FUNCTION TV SOURCE	Source	TIMER AV	AV
	Open/Close	ZOOM	Eject
SLEEP	Sleep	PROG SLEEP	Sleep
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
PL II	Dolby PL	SOUND DUAL	Dual
DSP/EQ	DSP/EQ	-/-- GUIDE	Guide
	I<<		I<<

Original		Replacement	
	>>I		>>I
	<<		<<
	>>		>>
	Stop		Stop
	Play	PLAY MODE	Play
	Pause		Pause
VOL	Vol+	VOL	Vol +
VOL	Vol-	VOL	Vol -
MUTE	Mute	MUTE	Mute
REPEAT	Repeat	REPEAT TEXT	Text
TUNING /CH	Tuning+	CH	Ch +
TUNING /CH	Tuning-	CH	Ch -
DISC MENU	Disc Menu	E-MANUAL D.MENU	D. Menu
MENU	Menu	TOP MENU MENU	Menu
TITLE MENU	Title Menu	SEARCH TV/R	TV/R
TOOLS	Tools	SETTINGS OPT	Options
INFO	Info	DISPLAY INFO	Info

Original		Replacement	
RETURN	Return	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
	Enter	OK	Ok
A	Red	A	Red
TUNER MEMORY B	Green/Tuner	B	Green
MO/ST C	Yellow/MO/ST	C	Yellow
CD RIPPING D	Blue/CD Ripping	D	Blue
DIMMER	Dimmer	AD SUBT	Subt
S.VOL	S.Vol	PICTURE FORMAT	Format
AUDIO UPSCALE P.BASS	P.Bass/Audio Upscale	ECO 3D	3D

Original	Replacement

Original		Replacement	
POWER	Power		Power
FUNCTION TV SOURCE	Function Tv	TIMER AV	AV
SLEEP	Sleep	PROG SLEEP	Sleep
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
<<	<<	<<	<<
>>	>>	>>	>>
Stop	Stop	Stop	Stop
Play	Play	PLAY MODE	Play

Original		Replacement	
	Pause		Pause
VOL	Vol+	+ VOL	Vol +
VOL	Vol-	VOL –	Vol -
MUTE	Mute	MUTE	Mute
TUNING /CH	CH+	+ CH	Ch +
TUNING /CH	CH-	CH –	Ch -
MENU	Menu	TOP MENU MENU	Menu
TOOLS	Tools	SETTINGS OPT	Options
INFO	Info	DISPLAY INFO	Info
RETURN	Return	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter	OK	Ok
A	Red	A	Red

Original		Replacement	
TUNER MEMORY B	Green	B	Green
MO/ST C	Yellow	C	Yellow
CD RIPPING D	Blue	D	Blue

Original	Replacement