Original		Replacement	
STANDBY	Standby		Power
DTV/VCR	DTV/VCR	MEDIA DISPLAY	Display / Media
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
RECALL	Recall	RETURN BACK	Back / Return
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ

Original		Replacement	
INFO	Info	ANGLE INFO	Info / Angle
MENU	Menu	HOME MENU	Menu / Home
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
CH+	CH+	+ CH PAGE	CH+ / Page+
CH-	CH-	CH PAGE −	CH- / Page-
CH+	Up		Up
CH-	Down		Down
VOL+	Right		Right
VOL-	Left		Left
OK	OK	OK	OK
VOL+	Vol +	+ VOL	Vol +
VOL-	Vol -	VOL −	Vol -
TEXT	Text	GOTO TEXT	Text / Goto
	Red	NETFLIX SEARCH	Red / Netflix / Search
RECLIST	Green	APP REPEAT	Green / APP / Repeat
TV/RADIO	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat

Original		Replacement		Original		Replacement	
STOP	Blue	Prime Video / RANDOM	Blue / Prime Video / Random				
TV/RADIO	Tv/Radio	PROGRAM TV/RADIO	TV/Radio /				
REC LIST	Rec List	LIST SMART	Smart / List				
STOP	Stop	HOLD	Stop / Hold				
PLAY/PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze				
PLAY/PAUSE	Play	SLOW	Play / Slow				
REV	<<	TUNE-	<< / Tune-				
FWD	>>	TUNE+	>> / Tune+				
RECORD	Record	REC MODE	Rec / Rec Mode				