Original		Replacement	
ON/STAND-BY	On/Standby		Power
OPEN/CLOSE	Open/Close	ZOOM	Eject
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
10+	10+	-/-- GUIDE	Guide
PLAY MODE	Play Mode	SHIFT + PLAY MODE	Shift + Play
DISPLAY(TV OUT)	iPod Display(Tv Out)	DISPLAY INFO	Info
MENU	iPod Menu	TOP MENU MENU	Menu
▶/II	iPod Play/Paus	PLAY MODE	Play

Original		Replacement	
DISPLAY	CD/USB Display	ECO 3D	3D
■	CD/USB Stop	■	Stop
▶/II	CD/USB	II	Pause
BASS/TREBLE	Bass/Treble	SETTINGS OPT	Options
EQUALIZER MODE	Equalizer Mode	SOUND DUAL	Dual
X-BASS	X-Bass	AD SUBT	Subt
MEMORY	Memory	REC MODE	Rec
CLEAR/DIMMER	Clear/Dimmer	CLEAR EXIT	Exit
VOLUME +	Vol +	+ VOL	Vol +
−	Vol -	VOL −	Vol -
CLOCK/TIMER	Clock/Timer	TIMER AV	AV
SLEEP	Sleep	PROG SLEEP	Sleep
FOLDER	Folder	PICTURE FORMAT	Format
▲	Preset Up	+ CH	Ch +
▼	Preset Down	CH −	Ch -
DEMO	Demo	RETURN BACK	Back
TUNING ▲	Up/Tuning+	▲	Up

Original		Replacement		Original	Replacement
TUNING	Down/ Tuni ng-		Down		
	>>I		>>I		
	I <<		I <<		
iPod	i Pod	A	Red		
CD	CD	C	Yel l ow		
TUNER(BAND)	Tuner (Band)	SEARCH TV/R	TV/ R		
ASPM	RDS ASPM	HOME SMART	Smart		
USB	USB	B	Gr een		
RDS PTY	RDS PTY	E-MANUAL D.MENU	D. Menu		
AUDIO IN	Audi o I n	D	Bl ue		
DISPLAY	RDS Di spl ay	SHIFT + DISPLAY INFO	Shi f t + I nf o		
TAPE	Tape	REPEAT TEXT	Text		
	Pl ay Tape		Ri ght		
	St op Tape		Lef t		
ENTER	Ent er	OK	Ok		