Mandis shop

Denon RC-1212

Original		Replacement		Original	Replacement
	Power		Power		
	Mute	MUTE	Mute		
1	1	1	1		
2	2	2	2		
3	3	3	3		
4	4	4	4		
5	5	5	5		
6	6	6	6		
+	+	+ VOL	Vol +		
-	-	VOL -	Vol -		
►/II	Play	PLAY MODE ►	Play		
►/II	Pause	II	Pause		
⏭	>>I	⏭	>>I		
⏮	I <<	⏮	I <<		

https://telecomandi.mandis.be/en/Denon/1508872-replacement-remote-control-for-Denon-RC-1212-3701023000/shtml