Mandis shop

RB-MCR350MO

Original		Replacement	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
ON	Standby/On		Power
FUNCTION	Function	OPT-TOOLS SETUP	Setup / OPT /
MEMORY	Memory	LIST SMART	Smart / List
BASS	Bass	LANG I/II AUDIO	Audio / Lang I/II
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
PRESET FOLDER SELECT	Preset/Folder Select	OK	OK
0	0	HDMI-SAT 0	0
OVER	Over	PC FAV MARKER	Fav / Marker / PC

Original		Replacement	
VOL −	Vol-	VOL −	Vol-
►/II	Play	SLOW ►	Play / Slow
►/II	Pause	STEP-FREEZE II	Pause / Step / Freeze
SOUND	Sound	TITLE SOUND	Sound / Title
+ VOL	Vol+	+ VOL	Vol+
■	Stop	HOLD ■	Stop / Hold
TUNING/ ⏮	I<</Tuning/File-	PRESET- ⏮	I<< / Preset-
TUNING/FILE+ ⏭	Tuning/File+/>>I	PRESET+ ⏭	>>I / Preset+
DISPLAY	Display	MEDIA DISPLAY	Display / Media
CD RANDOM	CD Random	SHIFT + CD-STB 3	Shift + 3
TAPE ►	Tape >	SHIFT + TAPE 5	Shift + 5
FM MODE/ REPEAT	FM	PROGRAM TV/ RADIO	TV/Radio /
◄◄	<< Tape	TUNE- ◄◄	<< / Tune-
►►	Tape >>	TUNE+ ►►	>> / Tune+
■	Stop Tape	SHIFT + HOLD ■	Shift + Stop /
●	Rec Tape	SHIFT + REC MODE ●	Shift + Rec / Rec Mode
●/II	Rec/Pause Tape	REC MODE ●	Rec / Rec Mode

https://telecommandes-mandis.be/en/1059360-79028-replacement-remote-control-for-RB-MCR350MO-6450671494.html