Mandis shop

COV30748163

Original		Replacement	
	Power		Power
FUNCTION	Function	TOP MENU MENU	Menu
VOL +	Vol+	VOL +	Vol +
VOL −	Vol-	VOL −	Vol -
MUTE	Mute	MUTE	Mute
	Equalizer	HOME SMART	Smart
WOOFER LEVEL ^	Woofer Level	CH +	Ch +
WOOFER LEVEL v	Woofer Level	CH −	Ch -
DRC	DRC	APP MEDIA	Media
REPEAT	Repeat	REPEAT TEXT	Text
	Moon	FAV PRE-CH	Pre Ch
SOUND EFFECT	Sound Effect	SOUND DUAL	Dual
>>I	>>I	>>I	>>I
I<<	I<<	I<<	I<<
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop

Original		Replacement	
+ FOLDER	Folder +		Up
FOLDER −	Folder-		Down
AV.SYNC	AV Sync	TIMER AV	AV
SLEEP	Sleep	PROG SLEEP	Sleep
VOLUME AUTO	Auto Volume	0	0
AUTO POWER	Auto Power	- / -- GUIDE	Guide
OPTICAL	Optical	SETTINGS OPT	Options
USB	USB	AD SUBT	Subt
	Bluetooth	ECO 3D	3D
LG TV	LG Tv	SEARCH TV/R	TV/R
PORT.IN	Port.In	PICTURE FORMAT	Format
INFO	Info	DISPLAY INFO	Info

https://telecommandes-mandis.be/en/LG/1059418-86046-replacement-remote-control-for-LG-COV30748163.html