Mandis shop

RM-SCP100

Original		Replacement	
	Power		Power
	DSG	SOUND DUAL	Dual
	Display	DISPLAY INFO	Info
	Play CD	PLAY MODE ▶	Play
	Pause	⏸	Pause
	Stop	■	Stop
	Play	APP MEDIA	Media
	I<< / Tuner -	⏮	I<<
	>>I / Tuner +	⏭	>>I
	Play / Rev Tape	SHIFT + PLAY MODE ▶	Shift + Play
	<<	⏪	<<
	>>	⏩	>>
	Dir Mode	1	1
	Play Mode	2	2
	Rec	REC MODE ●	Rec
	CD Repeat	HOME SMART	Smart
	Stereo / Mono	SETTINGS OPT	Options

Original		Replacement	
	Tuning Mode	3	3
	Up/Memory	▲	Up
	Left/Timer Set	◀	Left
	Enter/On/Off	OK	Ok
	Right/Timer	▶	Right
	Down/Sleep	▼	Down
	Down/Sleep	SHIFT + ⏻	Shift + Power
	Vol+	+ VOL	Vol +
	Vol-	VOL −	Vol -

https://telecommandes-mandis.be/en/Sony/1059676-81384-replacement-remote-control-for-Sony-RMSCP100.html