Original	Replacement
Power	Power
Red / Setup	Red / Netflix / Search
Red / Setup	Setup / OPT /
Green / APP	Green / APP / Repeat
Yellow / Vol	Yellow / YouTube / Repeat
Yellow / Vol	Vol -
Blue / Vol +	Blue / Prime Video / Random
Blue / Vol +	Vol +
Home / Menu	Menu / Home
Back	Back / Return
Up	Up
Left	Left
OK	OK
Right	Right
[≡]	Text / Goto
Down	Down
Mouse	Smart / List

Original	Replacement
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Mute	Mute / Dimmer
0	0
<X] / Exit	Exit / Cancel / Clear

https://telecommands.be/en/ODEN-NESTAR1610-3-151-replacement-remote-control-for-ODEN-NESTAR-G150.htm