Mandis shop

Philips 996580000768

Original		Replacement	
	Power		Power
COAX	Coax	1	1
OPTICAL	Optical	3	3
AUX	Aux	4	4
AUDIO IN	Audio In	6	6
USB	USB	GUIDE	Guide
	Bluetooth	0	0
HDMI ARC	HDMI ARC	PRE-CH	Pre Ch
	I<		I<<
	Play/Pause	PLAY MODE	Play
	I>		>>I
BASS +	Bass+		Up
BASS −	Bass-		Down
+	Vol+	VOL +	Vol +
−	Vol-	VOL −	Vol -
	Mute	MUTE	Mute
TREBLE +	Treble+	CH +	Ch +

Original		Replacement	
TREBLE −	Treble-	CH −	Ch -
SOUND	Sound	SOUND DUAL	Dual
SURROUND ON	Surround On	HOME SMART	Smart
OFF SURROUND	Surround Off	APP MEDIA	Media
AUDIO SYNC +	Audio Sync +		Right
− AUDIO SYNC	Audio Sync -		Left
NIGHT	Night	DISPLAY INFO	Info
DIM	DIM	E-MANUAL D.MENU	D. Menu

https://telecommandes-mandis.be/en/Philips/1060282-24152-replacement-remote-control-for-Philips-996580000768.html