Original		Replacement	
DVD Power	DVD Power	Power	Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
Open / Close	Open / Close	CLEAR EXIT	Exit
Setup	Setup	SETTINGS OPT	Options
Zoom	Zoom	ZOOM	Eject
3D Sound	3D Sound	ECO 3D	3D
Bookmark	Bookmark	FAV PRE-CH	Pre Ch
Volume Con.	Volume Con.	-/-- GUIDE	Guide

Original		Replacement	
<<	<<	<<	<<
>>	>>	>>	>>
Stop	Stop	Stop	Stop
Play / Pause	Play / Pause	PLAY MODE ▶	Play
Play / Pause	Play / Pause	II	Pause
I<<	I<<	I<<	I<<
>>I	>>I	>>I	>>I
Return	Return	RETURN BACK	Back
Step	Step	SHIFT + II	Shift + Pause
Clear	Clear	SHIFT + CLEAR EXIT	Shift + Exit
Top Menu	Top Menu	SHIFT + TOP MENU MENU	Shift + Menu
Top Menu	Top Menu	E-MANUAL D.MENU	D. Menu
Display	Display	DISPLAY INFO	Info
Menu	Menu	TOP MENU MENU	Menu
Up	Up	▲	Up
Left	Left	◀	Left
Enter	Enter	OK	Ok

Original	Replacement	Original	Replacement
Right	Right		
Down	Down		
Audio	SOUND DUAL		
Sub Title	AD SUBT		
Angle	PICTURE FORMAT		
Repeat	REPEAT TEXT		
Repeat A-B	SHIFT + REPEAT TEXT		