Original		Replacement	
POWER	Power		Power
GO TO	Goto	RETURN BACK	Back
MUTE	Mute	MUTE	Mute
SOURCE	Source	TIMER AV	AV
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
10+	10+	FAV PRE-CH	Pre Ch
STEP	Step	HOME SMART	Smart
SUBTITLE	Subtitle	AD SUBT	Subt

Original		Replacement	
ANGLE/ TTX	Angle/TTX	REPEAT TEXT	Text
AUDIO	Audio	SOUND DUAL	Dual
PBC/ SCAN	PBC/Scan	APP MEDIA	Media
TITLE	Title	ECO 3D	3D
■	Stop	■	Stop
▶II	Play	PLAY MODE ▶	Play
▶II	Pause	II	Pause
MODE	Mode	PICTURE FORMAT	Format
SETUP	Setup	SETTINGS OPT	Options
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
ENTER	Enter	OK	Ok
ZOOM	Yellow/Zoom	C	Yellow
MENU	Red/Menu	A	Red
⏮	Green	B	Green

Original		Replacement		Original	Replacement
	Blue	D	Blue		
	I<<		I<<		
	>>I		>>I		
TV/ RADIO	TV/Radio	SEARCH TV/R	TV/R		
REPEAT /DEL	Repeat/Del	SHIFT +	REPEAT TEXT Shift + Text		
PRO/ EPG	Pro/EPG	GUIDE	Guide		
DISPLAY	Display	DISPLAY INFO	Info		
/FAV	<<FAV		<<		
/PROT	>>/Prot		>>		