Original		Replacement	
	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
0	0	HDMI - SAT 0	0
TXT	TXT	GOTO TEXT	Text / Goto
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random

Original		Replacement	
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
?	?	TOP MENU D.MENU	D.Menu / Top
@	@	LIST SMART	Smart / List
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
BACK	Back	RETURN BACK	Back / Return
	Left		Left
OK	OK	OK	OK
	Right		Right
TOOLS	Tools	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
+	Vol+	+ VOL	Vol+
	Source	RDS AV INPUT	AV / Input / RDS
+ P	P+	+ CH PAGE	CH+ / Page+
–	Vol-	VOL –	Vol-
	Mute	DIMMER MUTE	Mute / Dimmer

Original		Replacement	
P –	P-	CH PAGE –	CH- / Page-
I<	I<	PRESET-	I<< / Preset-
>I	>I	PRESET+	>>I / Preset+
<<	<<	TUNE-	<< / Tune-
>>	>>	TUNE+	>> / Tune+
Rec	Rec	REC MODE	Rec / Rec Mode
Play	Play	SLOW	Play / Slow
Pause	Pause	STEP - FREEZE	Pause / Step / Freeze
Stop	Stop	HOLD	Stop / Hold
3D	3D	FORMAT PICTURE	Picture / Format
..O	..O	SIZE ZOOM	Zoom / Size
[...]..	[...]..	EQ SUBTITLE	Subtitle / EQ
NETFLIX	Netflix	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
My Media	My Media	MEDIA DISPLAY	Display / Media

Original	Replacement