Mandis shop

Optoma VDHDNL

Original		Replacement	
Mode	Mode	DISPLAY INFO	Info
Brightness	Brightness	+ CH	Ch +
ON	On		Power
OFF	Off	SHIFT +	Shift + Power
User1	User 1	A	Red
User2	User 2	B	Green
User3	User 3	C	Yellow
Contrast	Contrast	HOME SMART	Smart
Keystone	Keystone	APP MEDIA	Media
Aspect ratio	Aspect Ratio	PICTURE FORMAT	Format
Mute	Mute	MUTE	Mute
Sleep Timer	Sleep Timer	PROG SLEEP	Sleep
Volume+	Up / Volume+	+ VOL	Vol +
Volume+	Up / Volume+		Up
Volume-	Down / Volume-	VOL –	Vol -
Volume-	Down / Volume-		Down
Re-sync	Right / Re-Sync		Right

Original		Replacement	
Source	Left / Source		Left
Source	Left / Source	TIMER AV	AV
	Enter	OK	Ok
Menu	Menu	TOP MENU MENU	Menu
HDMI1	HDMI1	1	1
HDMI2	HDMI2	2	2
VGA1	VGA1	3	3
VGA2	VGA2	4	4
Video	Video	5	5
YPbPr	YPbPr	6	6

https://telecommandes-mandis.be/en/Optoma/1060964-60668-replacement-remote-control-for-Optoma-VDHDNL.html