Mandis shop

R-40A01

Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Source/[≡]	TIMER AV	AV
NORMAL/OK	Normal/OK/[≡i]	OK	Ok
PR	PR+	+ CH	Ch +
PR	Up		Up
PR	Down		Down
PR	PR-	CH −	Ch -

Original		Replacement	
	Right/[≡o]		Right
	Vol+	+ VOL	Vol +
	Vol-	VOL −	Vol -
	Left/[≡+]		Left
	Menu	TOP MENU MENU	Menu
	Mute	MUTE	Mute
RECALL	Recall/[≡?]	FAV PRE-CH	Pre Ch
SLEEP	Sleep/[≡♦]	PROG SLEEP	Sleep
SKIP	Red/Skip	A	Red
MOVE	Green/Movie	B	Green
DELETE	Yellow/Delete	C	Yellow
MODE	Blue/Mode	D	Blue
	[≡]	REPEAT TEXT	Text
	[≡x]	SEARCH TV/R	TV/R

https://telecommandes-mandis.be/en/Daewoo/1061042-23750-replacement-remote-control-for-Daewoo-R40A01-48B3740A01.html