Original		Replacement	
	Power TV		Power
1	1 TV	1	1
2	2 TV	2	2
3	3 TV	3	3
4	4 TV	4	4
5	5 TV	5	5
6	6 TV	6	6
7	7 TV	7	7
8	8 TV	8	8
9	9 TV	9	9
0/--	0/-- TV	0	0
AV	AV TV	TIMER AV	AV
+	Vol +	+ VOL	Vol +
-	Vol -	VOL -	Vol -
	Mute	MUTE	Mute
RETURN	Return TV	RETURN BACK	Back
PR	PR+ TV	+ CH	Ch +

Original		Replacement	
PR	PR- TV	CH -	Ch -
PLAY	Play TV	PLAY MODE	Play
REVERSE	<< TV	<<	<<
FORWARD	>> TV	>>	>>
RECORD	Record TV	REC MODE	Rec
STOP	Stop TV		Stop
PAUSE	Pause TV		Pause
EXIT	Exit TV	CLEAR EXIT	Exit
MENU	Menu TV	TOP MENU MENU	Menu
TEXT	Violet/Text TV	REPEAT TEXT	Text
PRESETS	Red/Presets TV	A	Red
LIST	Green/List TV	B	Green
INFO	Yellow/Info TV	C	Yellow
GUIDE	Blue/Guide TV	D	Blue
	Up TV		Up
	Down TV		Down
ZOOM+	Right/Zoom+		Right

TV

Original	Replacement	Original	Replacement
Left/Zoom- TV	Left	Right/Zoom+	Shift + Right
OK TV	Ok	Left/Zoom- AUX	Shift + Left
TV	TV/R	Exit AUX	Shift + Exit
Demo TV	Pre Ch	Menu AUX	Shift + Menu
VCR	Smart	Violet/Text AU	Shift + Text
SAT	Media	Return AUX	Shift + Back
DVD	Options	PR+ AUX	Shift + Ch +
AUX	Format	PR- AUX	Shift + Ch -
AMP	3D	1 AUX	Shift + 1
Power AUX	Shift + Power	2 AUX	Shift + 2
Red/Presets	Shift + Red	3 AUX	Shift + 3
Green/List AUX	Shift + Green	4 AUX	Shift + 4
Yellow/Info AU	Shift + Yellow	5 AUX	Shift + 5
Blue/Guide AUX	Shift + Blue	6 AUX	Shift + 6
Up AUX	Shift + Up	7 AUX	Shift + 7
OK AUX	Shift + Ok	8 AUX	Shift + 8
Down AUX	Shift + Down	9 AUX	Shift + 9

Original		Replacement		Original		Replacement
0/--	0 AUX	SHIFT + 0	Shift + 0			
PLAY	Play AUX	SHIFT + PLAY MODE	Shift + Play			
REVERSE	<< AUX	SHIFT + <<	Shift + <<			
FORWARD	>> AUX	SHIFT + >>	Shift + >>			
STOP	Stop AUX	SHIFT + ■	Shift + Stop			
RECORD	Record AUX	SHIFT + REC MODE	Shift + Rec			
PAUSE	Pause AUX	SHIFT + II	Shift + Pause			
AV	AV AUX	SHIFT + TIMER AV	Shift + AV			
DEMO	Demo AUX	SHIFT + FAV PRE-CH	Shift + Pre Ch			

Original	Replacement
Power DVD	Power
Red/Presets	Red
Green/List DVD	Green
Yellow/Info DVD	Yellow
Blue/Guide DVD	Blue
Violet/Text DVD	Text
Up DVD	Up
Down DVD	Down
Right/Zoom+	Right
Left/Zoom- DVD	Left
OK DVD	Ok
Exit DVD	Exit
Menu DVD	Menu
Vol +	Vol +
Vol -	Vol -
Mute	Mute
Return DVD	Back

Original	Replacement
PR+ DVD	Ch +
PR- DVD	Ch -
1 DVD	1
2 DVD	2
3 DVD	3
4 DVD	4
5 DVD	5
6 DVD	6
7 DVD	7
8 DVD	8
9 DVD	9
0 DVD	0
AV DVD	AV
Demo DVD	Pre Ch
Play DVD	Play
<< DVD	<<
>> DVD	>>

Original	Replacement
Record DVD	Rec
Stop DVD	Stop
Pause	Pause
TV	TV/R
VCR	Smart
SAT	Media
DVD	Options
AUX	Format
AMP	3D
Power VCR	Shift + Power
Red/Presets	Shift + Red
Green/List VCR	Shift + Green
Yellow/Info VC	Shift + Yellow
Blue/Guide VCR	Shift + Blue
Violet/Text VC	Shift + Text
Exit VCR	Shift + Exit
Menu VCR	Shift + Menu

Original	Replacement
Up VCR	Shift + Up
Down VCR	Shift + Down
Right/Zoom+	Shift + Right
Left/Zoom- VCR	Shift + Left
OK VCR	Shift + Ok
Return VCR	Shift + Back
PR+ VCR	Shift + Ch +
PR- VCR	Shift + Ch -
1 VCR	Shift + 1
2 VCR	Shift + 2
3 VCR	Shift + 3
4 VCR	Shift + 4
5 VCR	Shift + 5
6 VCR	Shift + 6
7 VCR	Shift + 7
8 VCR	Shift + 8
9 VCR	Shift + 9

Original	Replacement	Original	Replacement
0/-- 0 VCR	SHIFT + 0 Shift + 0		
REVERSE << VCR	SHIFT + << Shift + <<		
FORWARD >> VCR	SHIFT + >> Shift + >>		
PLAY Play VCR	SHIFT + PLAY MODE Shift + Play		
AV AV VCR	SHIFT + TIMER AV Shift + AV		
STOP Stop VCR	SHIFT + Shift + Stop		
RECORD Record VCR	SHIFT + REC MODE Shift + Rec		
PAUSE Pause VCR	SHIFT + Shift + Pause		

Original		Replacement	
	Power		Power
TV	TV	SEARCH TV/R	TV/R
VCR	VCR	HOME SMART	Smart
SAT	SAT	APP MEDIA	Media
DVD	DVD	SETTINGS OPT	Options
AUX	AUX	PICTURE FORMAT	Format
AMP	AMP	ECO 3D	3D
PRESETS	Red/Presets	A	Red
LIST	Green/List	B	Green
INFO	Yellow/Info	C	Yellow
GUIDE	Blue/Guide	D	Blue
TEXT	Violet/Text	REPEAT TEXT	Text
	Up		Up
	Down		Down
ZOOM	Right/Zoom+		Right
ZOOM	Left/Zoom-		Left
OK	OK	OK	Ok

Original		Replacement	
EXIT	Exit	CLEAR EXIT	Exit
MENU	Menu	TOP MENU MENU	Menu
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
	Mute	MUTE	Mute
RETURN	Return	RETURN BACK	Back
PR+	PR+	+ CH	Ch +
PR-	PR-	CH −	Ch -
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9

Original		Replacement		Original		Replacement	
0/--	0	0	0				
AV	AV	TIMER AV	AV				
DEMO	Demo	FAV PRE-CH	Pre Ch				
REVERSE	<<	<<	<<				
PLAY	Play	PLAY MODE	Play				
FORWARD	>>	>>	>>				
RECORD	Record	REC MODE	Rec				
STOP	Stop		Stop				
PAUSE	Pause		Pause				

Original		Replacement	
	Power		Power
TV	TV	SEARCH TV/R	TV/R
VCR	VCR	HOME SMART	Smart
SAT	SAT	APP MEDIA	Media
DVD	DVD	SETTINGS OPT	Options
AUX	AUX	PICTURE FORMAT	Format
AMP	AMP	ECO 3D	3D
PRESETS	Red/Presets	A	Red
INFO	Yellow/Info	C	Yellow
GUIDE	Blue/Guide	D	Blue
TEXT	Violet/Text	REPEAT TEXT	Text
	Up		Up
	Down		Down
ZOOM+	Right/Zoom+		Right
ZOOM-	Left/Zoom-		Left
OK	OK	OK	Ok
EXIT	Exit	CLEAR EXIT	Exit

Original		Replacement	
MENU	Menu	TOP MENU MENU	Menu
+	Vol +	+ VOL	Vol +
-	Vol -	VOL -	Vol -
	Mute	MUTE	Mute
RETURN	Return	RETURN BACK	Back
PR+	PR+	+ CH	Ch +
PR-	PR-	CH -	Ch -
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0/--	0	0	0

Original		Replacement		Original	Replacement
AV	AV	TIMER AV	AV		
REVERSE	<<	<<	<<		
PLAY	Play	PLAY MODE	Play		
FORWARD	>>	>>	>>		
RECORD	Record	REC MODE	Rec		
STOP	Stop	■	Stop		
PAUSE	Pause	❚❚	Pause		