Original		Replacement	
Power	Power	Power	Power
Home	Home	HOME SMART	Smart
[·]	[·]	APP MEDIA	Media
Play	Play	PLAY MODE ▶	Play
ALL▶	All>	FAV PRE-CH	Pre Ch
<<	<<	«	<<
Pause	Pause	❚❚	Pause
>>	>>	»	>>
I<	I<	⏮	I<<
Stop	Stop	■	Stop
>I	>I	⏭	>>I
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
ENTER	Enter	OK	Ok
Rotate	Rotate	SETTINGS OPT	Options

Original		Replacement	
Title	Title	DISC NAV LIST	List
Zoom	Zoom	ZOOM ⏏	Eject
RETURN	Return	RETURN BACK	Back
Menu	Menu	TOP MENU MENU	Menu
+	Vol+	+ VOL	Vol +
−	Vol-	VOL −	Vol -
Mute	Mute	MUTE	Mute
Audio	Audio	SOUND DUAL	Dual
Subtitle	Subtitle	AD SUBT	Subt
♦	♦	PICTURE FORMAT	Format
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7

Original		Replacement	
8	8	8	8
9	9	9	9
0	0	0	0
Info	Info	DISPLAY INFO	Info
Search	Search	SHIFT + SEARCH TV/R	Shift + TV/R
Movies	Red/Movies	A	Red
Music	Green/Music	B	Green
Pictures	Blue/Pictures	D	Blue
Settings	Yellow/Settings	C	Yellow
Slow	Slow	ECO 3D	3D
Angle	Angle	CLEAR EXIT	Exit
Thumbnails	Thumbnails	-/-- GUIDE	Guide
TV out	Tv Out	SEARCH TV/R	TV/R
Repeat	Repeat	REPEAT TEXT	Text
Repeat A-B	Repeat A-B	TIMER AV	AV
A1	A1	PROG SLEEP	Sleep
A2	A2	E-MANUAL D.MENU	D. Menu

Original	Replacement