Original	Replacement
Power	Power
Red/Timer	Red / Netflix / Search
Red/Timer	Sleep / Timer
Green/O	Green / APP / Repeat
Yellow/[<>]	Shift + Picture / Format
Yellow/[<>]	Yellow / YouTube / Repeat
Blue/I-II	Blue / Prime Video / Random
Blue/I-II	Audio / Lang I/II
[≡]	Text / Goto
[+]	Stop / Hold
[:≡]	Smart / List
[?]	Play / Slow
Smart ♪	Sound / Title
Smart Picture	Picture / Format
Up	Up
Left	Left
OK	OK

Original	Replacement
Right	Right
Down	Down
Menu	Menu / Home
[ ]	D. Menu / Top
Vol +	Vol +
A/CH	Display / Media
P+	CH+ / Page+
Vol -	Vol -
Mute	Mute / Dimmer
P-	CH- / Page-
1	1
2	2
3	3
4	4
5	5
6	6
7	7

Original		Replacement		Original	Replacement
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
[i +]	Info / Angle	ANGLE INFO			
0	0	HDMI - SAT 0	0		
AV	AV / Input / RDS	RDS AV INPUT			