Mandis shop

RRMCG0144AWSA

Original		Replacement	
ON/ STAND-BY	On/Standby		Power
VOLUME	Vol+	VOL +	Vol +
VOLUME	Vol-	VOL −	Vol -
X-BASS/ EQUALIZER	X-Bass/Equalizer	HOME SMART	Smart
VIDEO/AUX	Video/AUX	A	Red
TAPE (1↔2)	Tape (1↔2)	D	Blue
TUNER (BAND)	Tuner(Band)	B	Green
CD	CD	C	Yellow
●II	Rec/Pause Tape 2	REC MODE ●	Rec
◀◀	<< Tape 2	«	<<
▶▶	>> Tape 2	»	>>
TAPE 2 ▶	Play Tape 2	◀	Left
▶ TAPE 1	Play Tape 1	▶	Right
TAPE 1 ■ TAPE 2	Stop Tape	OK	Ok
PRESET	Tuner Preset Up	+ CH	Ch +
PRESET	Tuner Preset	CH −	Ch -
PTY. TI	PTY TI	RETURN BACK	Back

Original		Replacement	
1	Disc CD 1	1	1
2	Disc CD 2	2	2
3	Disc CD 3	3	3
DISC SKIP	Disc Skip	APP MEDIA	Media
⏮	I<<|<< CD	«	I<<
⏭	>>|>>I CD	»	>>I
■	Stop CD	■	Stop
▶	Play CD	PLAY MODE ▶	Play
MEMORY	Memory CD	ECO 3D	3D
CLEAR	Clear	CLEAR EXIT	Exit
RANDOM	Random	SEARCH TV/R	TV/R
II	Pause CD	II	Pause

https://telecommandes-mandis.be/en/Sharp/1061610-2982-replacement-remote-control-for-Sharp-RRMCG0144AWSA.html