Original		Replacement	
Power	Power	Power	Power
Source	Source	TIMER AV	AV
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
GUIDE	Guide	GUIDE	Guide
Smart/Colors	Smart/Colors	SHIFT + HOME SMART	Shift + Smart
HOME	Home	HOME SMART	Smart
CH+	CH+	CH +	Ch +
CH-	CH-	CH −	Ch -

Original		Replacement	
VOL +	Vol+	VOL +	Vol +
VOL −	Vol-	VOL −	Vol -
Mute	Mute	MUTE	Mute
MENU	Menu	TOP MENU MENU	Menu
INFO	Info	DISPLAY INFO	Info
BACK	Back	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
Up	Up	Up	Up
Down	Down	Down	Down
Right	Right	Right	Right
left	left	Left	Left
OK	OK	OK	Ok
NETFLIX	Netflix	SHIFT + APP MEDIA	Shift + Media
prime video	Prime Video	PICTURE FORMAT	Format
YouTube	You Tube	APP MEDIA	Media
Google Play Movies & TV	Google Play	ECO 3D	3D
MTS	MTS	SETTINGS OPT	Options

Original		Replacement		Original	Replacement
TEXT	Text	REPEAT TEXT	Text		
SUB	Sub	AD SUBT	Subt		
TV	TV	SEARCH TV/R	TV/R		
▶II	Play	PLAY MODE ▶	Play		
▶II	Pause	II	Pause		
◀◀	<<	≪	<<		
▶▶	>>	≫	>>		
■	Stop	■	Stop		
	Red	A	Red		
	Green	B	Green		
	Yellow	C	Yellow		
	Blue	D	Blue		