Mandis shop

Philips PPX3414EU

Original	Replacement	Original	Replacement
Power	Power		
Zoom	Eject		
Back	Back		
Up	Up		
Left	Left		
OK	Ok		
Right	Right		
Down	Down		
<<	<<		
Play / Pause	Play		
Play / Pause	Pause		
>>	>>		
☼ -	Ch -		
☼ +	Ch +		
Vol -	Vol -		
Mute	Mute		
Vol +	Vol +		