Original		Replacement	
POWER	Power	POWER	Power
TV/RADIO	TV / Radio	SEARCH TV/R	TV/R
SOURCE	Source	TIMER AV	AV
OPEN/CLOSE	Open / Close	ZOOM	Eject
LANGUAGE	Language	SOUND DUAL	Dual
RETURN	Return	RETURN BACK	Back
SLOW	Slow	SHIFT + PLAY MODE	Shift + Play
REPEAT	Repeat	SHIFT + REPEAT TEXT	Shift + Text
ZOOM	Zoom	SHIFT + ZOOM	Shift + Eject
A-B	A-B	E-MANUAL D.MENU	D. Menu
STEP	Step	SHIFT +	Shift + Pause
ANGLE	Angle	PICTURE FORMAT	Format
DISPLAY	Display	DISPLAY INFO	Info
SUBTITLE	Subtitle	AD SUBT	Subt
TIME	Time	SHIFT + TIMER AV	Shift + AV
MENU	Menu	TOP MENU MENU	Menu
SETUP	Setup	SETTINGS OPT	Options

Original		Replacement	
TITLE/TTX	Title / TTX	REPEAT TEXT	Text
UP	Up		Up
	Left		Left
ENTER	Enter	OK	Ok
	Right		Right
DOWN	Down		Down
EPG	EPG	GUIDE	Guide
P/N	P/N	HOME SMART	Smart
PROG/EXIT	Prog / Exit	PROG SLEEP	Sleep
PROG/EXIT	Prog / Exit	CLEAR EXIT	Exit
PLAY/PAUSE	Play / Pause	PLAY MODE	Play
PLAY/PAUSE	Play / Pause		Pause
STOP	Stop		Stop
REC	Rec	REC MODE	Rec
FAV	Fav	FAV PRE-CH	Pre Ch
USB	USB	APP MEDIA	Media
VOL+	Vol+	+ VOL	Vol +

Original		Replacement	
VOL-	Vol-	VOL –	Vol -
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0/10	0 / 10	0	0
L/R	L / R	DISC NAV LIST	List
MUTE	Mute	MUTE	Mute
REV	Rev	«	<<
FWD	Fwd	»	>>
PREV	Prev	⏮	I<<
NEXT	Next	⏭	>>I

Original		Replacement	
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue