Mandis shop

RC26

Original		Replacement	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
M.CALL	GE M.Call	FAV PRE-CH	Pre Ch
EFFECT	GE Effect	GUIDE	Guide
I<< CD	I<< CD	I<<	I<<
>>I CD	>>I CD	>>I	>>I
Stop CD	Stop CD	Stop	Stop
Play/Pause CD	Play/Pause CD	PLAY MODE	Play
<< Tape A	<< Tape A	Down	Down
>> Tape A	>> Tape A	Up	Up
< Tape A	< Tape A	Left	Left
> Tape A	> Tape A	Right	Right
Stop Tape A	Stop Tape A	OK	Ok
<< Tape B	<< Tape B	SHIFT +	Shift + Down
>> Tape B	>> Tape B	SHIFT +	Shift + Up
< Tape B	< Tape B	SHIFT +	Shift + Left
> Tape B	> Tape B	SHIFT +	Shift + Right

Original		Replacement	
Pause Tape B	Pause Tape B	SHIFT +	Shift + Pause
REC	Rec Tape B	SHIFT + REC MODE	Shift + Rec
Stop Tape B	Stop Tape B	SHIFT + OK	Shift + Ok
BAND	Band	HOME SMART	Smart
TUNER P.SCAN	Tuner/P.Scan	CH −	Ch -
SCAN	Tuner/P.Scan	+ CH	Ch +
MUTE	Mute	MUTE	Mute
VOLUME CONTROL	Volume	+ VOL	Vol +
VOLUME CONTROL	Volume Control-	VOL −	Vol -
PRESENCE	Presence	TOP MENU MENU	Menu
OFF	Off	CLEAR EXIT	Exit
DISPLAY	Display	DISPLAY INFO	Info
TUNER	Tuner	B	Green
AUX	AUX	A	Red
PHONO	Phono	C	Yellow

https://telecommandes-mandis.be/en/Kenwood/1062243-82817-replacement-remote-control-for-Kenwood-RXD-27L-RC-26.html