Original	Replacement	Original	Replacement
1	1	Memory	Fav / Marker / PC
2	2	Mute	Mute / Dimmer
3	3	FRQ Direct	Play / Slow
Power On	Power	Center	Sleep / Timer
Power Off	Shift + Power	Up	Up
4	4	Menu	Menu / Home
5	5	Tune	I << / Preset-
6	6	Preset	>>I / Preset+
CH+	CH+ / Page+	- / Back	Left
Vol +	Vol +	Enter	OK
7	7	+/ Forward	Right
8	8	FM Mono	Pause / Step / Freeze
9	9	Band	Stop / Hold
CH-	CH- / Page-	Swoofer	Subtitle / EQ
Vol -	Vol -	Down	Down
+10	Guide / EPG / -/--	Surround	Eject / Surround
0	0	EQ	Shift + Subtitle / EQ

Original		Replacement	
DISC2 DYN	DYN	TITLE SOUND	Sound / Title
DISC3 REC	Rec	REC MODE	Rec / Rec Mode
DISC4 ZONE	Zone	TUNE-	<< / Tune-
DISC5 SUR+	Sur +	SHIFT + SURROUND	Shift + Eject / Surround
CD	CD	SHIFT + CD-STB 3	Shift + 3
TUN	Tun	SHIFT + TUNER 6	Shift + 6
TAPE	Tape	SHIFT + TAPE 5	Shift + 5
EXT	EXT	RDS AV INPUT	AV / Input / RDS
PROG 2CH	2 CH	LANG I/II AUDIO	Audio / Lang I/II
RANDOM PL C DIGEST	PL C	NETFLIX SEARCH	Red / Netflix / Search
REPEAT PL M TITLE	PL M	APP REPEAT	Green / APP / Repeat
DISC- 5CH P-SCAN	5 CH	YouTube REPEAT A-B	Yellow / YouTube / Repeat
DISC+ 7CH OPEN	7 CH	Prime Video RANDOM	Blue / Prime Video / Random
V1	V1/ DVD	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
V1	V1/ DVD	SHIFT + DVD 2	Shift + 2
V2	V2	SHIFT + APP REPEAT	Shift + Green / APP /
V3	V3	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube / Repeat

Original		Replacement	
V4	V4	SHIFT + Prime Video RANDOM	Shift + Blue / Prime
V5	V5	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
DISPLAY DISP	Display	MEDIA DISPLAY	Display / Media
AUDIO TAPE2	Tape 2	SHIFT + TV 1	Shift + 1
ANGLE PHONO	Phono	SHIFT + VIDEO 4	Shift + 4
SBTITLE TONE	Tone	GOTO TEXT	Text / Goto
ZOOM D-SLT	D-SLT	TOP MENU D.MENU	D. Menu / Top
RESUME SCAN INPUT 1	Scan	TUNE+	>> / Tune+
REPEAT PTY INPUT 2	PTY	ANGLE INFO	Info / Angle
A-B P-TUN INPUT 3	P-Tun	PROGRAM TV/ RADIO	TV/ Radio /
GOTO TP TV/VCR	TP	CLEAR EXIT CANCEL	Exit / Cancel / Clear
SLOW TA RECORD	TA	RETURN BACK	Back / Return
ASPECT	Aspect	FORMAT PICTURE	Picture / Format
DISP	Disp	SHIFT + MEDIA DISPLAY	Shift + Display / Media
PIP	PIP	OPT-TOOLS SETUP	Setup / OPT /
POP	POP	SIZE ZOOM	Zoom / Size
OUTPUT	Output	LIST SMART	Smart / List

Original	Replacement	Original	Replacement
POWER Power	SHIFT + OK Shift + OK		

Original	Replacement	Original	Replacement
1	1	Play	Play / Slow
2	2	Menu	Menu / Home
3	3	Up	Up
Power On	Power	OSD	Smart / List
Power Off	Shift + Power	I <<	I << / Preset-
4	4	>>I	>>I / Preset+
5	5	- / Back	<< / Tune-
6	6	- / Back	Left
Vol +	Vol +	Enter	OK
7	7	+/ Forward	>> / Tune+
8	8	+/ Forward	Right
9	9	Pause	Pause / Step / Freeze
Vol -	Vol -	Stop	Stop / Hold
Ten (+10)	Guide / EPG / -/--	Search-	CH- / Page-
0	0	Down	Down
Clear (X)	Exit / Cancel / Clear	Search+	CH+ / Page+
Mute	Mute / Dimmer	Random (DYN)	Blue / Prime Video / Random

Original	Replacement	Original	Replacement
DISC3 REC — PAL (Rec)	TOP MENU D.MENU — D. Menu / Top	SLOW TA RECORD — Slow	SHIFT + SLOW ▶ — Shift + Play /
DISC4 ZONE — HD Mode	OPT-TOOLS SETUP — Setup / OPT /	POWER — Power	SHIFT + OK — Shift + OK
DISC5 SUR+ — DIM (SUR+)	SHIFT + DIMMER MUTE — Shift + Mute / Dimmer		
PROG 2CH — Prog (2CH)	RDS AV INPUT — AV / Input / RDS		
RANDOM PL C DIGEST — Screen (PL C)	FORMAT PICTURE — Picture / Format		
REPEAT PL M TITLE — Title (PL M)	TITLE SOUND — Sound / Title		
REPEAT PL M TITLE — Repeat	APP REPEAT — Green / APP / Repeat		
DISC- 5CH P-SCAN — Prog-Scan	PROGRAM TV/RADIO — TV/Radio /		
DISC+ 7CH OPEN — Open (7CH)	SURROUND ⏏ — Eject / Surround		
DISPLAY DISP — Display	MEDIA DISPLAY — Display / Media		
AUDIO TAPE2 — Audio	LANG I/II AUDIO — Audio / Lang I/II		
ANGLE PHONO — Angle	ANGLE INFO — Info / Angle		
SBTITLE TONE — Subtitle	EQ SUBTITLE — Subtitle / EQ		
ZOOM D-SLT — Zoom	SIZE ZOOM — Zoom / Size		
RESUME SCAN INPUT 1 — Resume	RETURN BACK — Back / Return		
A-B P-TUN INPUT 3 — A-B	YouTube REPEAT A-B — Yellow / YouTube / Repeat		
GOTO TP TV/VCR — Goto	GOTO TEXT — Text / Goto		

Original		Replacement	
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
POW ON	Power On		Power
WER OFF	Power Off	SHIFT +	Shift + Power
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
VOL +	Vol +	VOL +	Vol +
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
VOL -	Vol -	VOL -	Vol -
+10	TEN (+10)	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
FRQ DIRECT	Play	SLOW ▶	Play / Slow

Original		Replacement	
TUNE	I <<	PRESET-	I << / Preset-
PRESET	>>I	PRESET+	>>I / Preset+
ENT	Open (ENT)	OK	OK
ENT	Open (ENT)	SURROUND	Eject / Surround
FM MONO	Pause	STEP - FREEZE	Pause / Step / Freeze
BAND	Stop	HOLD	Stop / Hold
SEARCH- SUB	Search-	CH PAGE -	CH- / Page-
SEARCH+ SUR	Search+	CH PAGE +	CH+ / Page+
DISC1 EQ	Disc 1	SHIFT + TV 1	Shift + 1
DISC2 DYN	Disc 2	SHIFT + DVD 2	Shift + 2
DISC3 REC	Disc 3	SHIFT + CD - STB 3	Shift + 3
DISC4 ZONE	Disc 4	SHIFT + VIDEO 4	Shift + 4
DISC5 SUR+	Disc 5	SHIFT + TAPE 5	Shift + 5
PROG 2CH	Program (2CH)	PROGRAM TV/RADIO	TV/Radio /
RANDOM PL C DIGEST	Random (PL C)	Prime Video RANDOM	Blue / Prime Video / Random
REPEAT PL M TITLE	Repeat (PL M)	APP REPEAT	Green / APP / Repeat
DISC+ 7CH OPEN	Disc+ (7CH)	EQ SUBTITLE	Subtitle / EQ

Original		Replacement		Original	Replacement
DISPLAY DISP	Display (DISP	MEDIA DISPLAY	Display / Media		
RESUME SCAN INPUT 1	Scan	TUNE+	>> / Tune+		
REPEAT PTY INPUT 2	Time (PTY)	TIMER SLEEP	Sleep / Timer		
A-B P-TUN INPUT 3	A-B (P-Tun)	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
GOTO TP TV/VCR	Review (TP)	TUNE-	<< / Tune-		
SLOW TA RECORD	Clear (TA)	TOP MENU D.MENU	D. Menu / Top		
POWER	Power	SHIFT + OK	Shift + OK		