Original		Replacement	
POWER	Power		Power
SOURCE	Source	TIMER AV	AV
HDMI	HDMI	APP MEDIA	Media
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
TTX/MIX	TTX/MIX	REPEAT TEXT	Text
PRE-CH	PRE-CH	FAV PRE-CH	Pre Ch
MUTE	Mute	MUTE	Mute
CH LIST	CH List	DISC NAV LIST	List

Original		Replacement	
	Vol+	+ VOL	Vol +
	Vol-	VOL −	Vol -
P	P+	+ CH	Ch +
P	P-	CH −	Ch -
HOME	Home	HOME SMART	Smart
MENU	Menu	TOP MENU MENU	Menu
GUIDE	Guide	- / -- GUIDE	Guide
TOOLS	Tools	SETTINGS OPT	Options
CLOCK INFO	Info	DISPLAY INFO	Info
RETURN	Return	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
A	Red	A	Red
B	Green	B	Green

Original		Replacement		Original		Replacement	
C	Yellow	C	Yellow				
D	Blue	D	Blue				
DUAL I-II	Dual I-II	SOUND DUAL	Dual				
CONTENT	Content	E-MANUAL D.MENU	D. Menu				
3D	3D	ECO 3D	3D				
ALARM	Alarm	SEARCH TV/R	TV/R				
P.SIZE	P.Size	PICTURE FORMAT	Format				
SUBT.	Subt.	AD SUBT	Subt				
Enter	Enter	OK	Ok				
<<|<<	<<|<<	<<	<<				
Pause	Pause	Pause	Pause				
>>|>>|	>>|>>|	>>	>>				
Play	Play	PLAY MODE	Play				
Rec	Rec	REC MODE	Rec				
Stop	Stop	Stop	Stop				