Mandis shop

LG COV34445442

Original		Replacement	
	Power		Power
F	F	TOP MENU MENU	Menu
VOL +	Vol+	+ VOL	Vol +
−	Vol-	VOL −	Vol -
ASC	ASC	HOME SMART	Smart
	Mute	MUTE	Mute
STANDARD	Standard	SOUND DUAL	Dual
CINEMA	Cinema	SEARCH TV/R	TV/R
▶/II	Play	PLAY MODE ▶	Play
▶/II	Pause	II	Pause
⏭	>>I	⏭	>>I
⏮	I<<	⏮	I<<
DRC ON	DRC On	A	Red
DRC OFF	DRC Off	B	Green
WOOFER LEVEL +	Woofer Level+	+ CH	Ch +
WOOFER LEVEL −	Woofer Level-	CH −	Ch -
AUTO POWER ON	Auto Power On	C	Yellow

Original		Replacement	
AUTO POWER OFF	Auto Power Off	D	Blue

https://telecommandes-mandis.be/en/LG/1063356-82936-replacement-remote-control-for-LG-COV34445442.html