Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Prev		I<<
	Prev	GUIDE	Guide
	Next		>>I
	Next	PRE-CH	Pre Ch
	Menu	MENU	Menu
	Info	INFO	Info

Original		Replacement	
	Up		Up
	Left		Left
OK	OK	OK	Ok
	Right		Right
	Down		Down
Audio	Audio	DUAL	Dual
PVR	PVR	SMART	Smart
Exit	Exit	EXIT	Exit
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	Volume+	VOL +	Vol +
	Volume-	VOL −	Vol -
	File List	LIST	List
	Mute	MUTE	Mute
	Channel+	CH +	Ch +

Original	Replacement	Original	Replacement
Channel-	CH – Ch -		
<<	<< <<		
Play / Pause	PLAY MODE ▶ Play		
Play / Pause	❚❚ Pause		
Stop	■ Stop		
>>	>> >>		
www	APP MEDIA Media		
Subtitle	AD SUBT Subt		
Timer	TIMER AV AV		
Timer	PROG SLEEP Sleep		
Rec	REC MODE ● Rec		
TV	SEARCH TV/R TV/R		
Radio	SHIFT + SEARCH TV/R Shift + TV/R		
Text	REPEAT TEXT Text		
Help	E-MANUAL D.MENU D. Menu		