Original		Replacement	
POWER	Power		Power
FUNCTION	Function	TOP MENU MENU	Menu
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0/10	0/10	0	0
+10	+10	-/-- GUIDE	Guide
DISC SKIP	Disc Skip	D	Blue
▶▶I	Preset >>I	▶▶I	>>I
I◀◀	I<< Preset	I◀◀	I<<
▶/◀▶	Play/<>	PLAY MODE ▶	Play

Original		Replacement	
❚❚	Pause	❚❚	Pause
■	Stop	■	Stop
▶▶	>>	▶▶	>>
◀◀	<<	◀◀	<<
^	Album Up	+ CH	Ch +
v	Album Down	CH −	Ch -
ENTER	Enter	OK	Ok
SLEEP	Sleep	PROG SLEEP	Sleep
REPEAT	Repeat	REPEAT TEXT	Text
PLAY MODE	Play Mode	SHIFT + PLAY MODE ▶	Shift + Play
SET	Clock Timer Set	HOME SMART	Smart
SELECT	Clock Timer	APP MEDIA	Media
CLEAR	Clear	CLEAR EXIT	Exit
VOLUME +	Vol +	+ VOL	Vol +
−	Vol -	VOL −	Vol -
	Edit	FAV PRE-CH	Pre Ch
	Band	B	Green

Original	Replacement	Original	Replacement
Spectrum	SETTINGS OPT Options		
Tuner Mode	SEARCH TV/R TV/R		
Karaoke	ECO 3D 3D		
DISPLAY Display	DISPLAY INFO Info		
SOUND Sound	SOUND DUAL Dual		
GEQ	A Red		
Tape A/B	C Yellow		
Tuner Memory	TIMER AV AV		
Surround	AD SUBT Subt		