Mandis shop

CU- A005

Original		Replacement	
AMP POWER	AMP Power		Power
VOLUME +	Volume+	+ VOL	Vol +
– VOL	Volume-	VOL –	Vol -
MUTING	Muting	MUTE	Mute
TAPE 1	Tape 1	A	Red
TAPE 2	Tape 2	B	Green
CD	CD	C	Yellow
TUNER	Tuner	D	Blue
LINE	Line	HOME SMART	Smart
PHONO	Phono	APP MEDIA	Media
CD POWER	CD Power	1	1
	Stop CD		Stop
	Play CD	PLAY MODE	Play
	>>I CD		>>I
	I << CD		I <<
TUNER POWER	Tuner Power	2	2
	Station+	+ CH	Ch +

Original		Replacement	
	Station-	CH –	Ch -
TAPE POWER	Tape Power	3	3
	>> Deck 1		>>
	<< Deck 1		<<
DISC SELECT	Disc Select	ECO 3D	3D
	> Tape Deck 1		Right
	< Tape Deck 1		Left
	Stop Deck 1	OK	Ok
TAPE SELECT	Tape Select	RETURN BACK	Back
	> Tape Deck 2	9	9
	< Tape Deck 2	7	7
	Stop Deck 2	8	8
	>> Deck 2	FAV PRE-CH	Pre Ch
	<< Deck 2	GUIDE	Guide

https://telecomands.com/Pioneer/1680-1984-replacement-remote-control-for-Pioneer-CU-A005.htm