Mandis shop

RM-S616

| Original | Replacement |
|---|---|
| Power | Power |
| CD | Yellow |
| I<< CD | I<< |
| >>I CD | >>I |
| Play CD | Play |
| Stop CD | Stop |
| Tape | Blue |
| << Deck A | Down |
| << Deck B | Shift + Down |
| >> Deck A | Up |
| >> Deck B | Shift + Up |
| < Deck A | Left |
| < Deck B | Shift + Left |
| >Deck A | Right |
| > Deck B | Shift + Right |
| Stop Deck A | Ok |
| Stop Deck B | Shift + Ok |

| Original | Replacement |
|---|---|
| Rec Deck B | Shift + Rec |
| Pause Deck B | Shift + Pause |
| Stop Rec Deck | Shift + Stop |
| Tuner | Red |
| Preset+ | Ch + |
| Preset- | Ch - |
| Phono | Green |
| Vol+ | Vol + |
| Vol- | Vol - |

https://telecommandes-mandis.be/en/Sony/1064290-94819-replacement-remote-control-for-Sony-RM-S616.html