Mandis shop

Pioneer AXD7472

Original		Replacement	
	Power		Power
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
CD	CD	CD - STB 3	3
PHONO	Phono	VIDEO 4	4
TAPE	Tape	TAPE 5	5
TUNER	Tuner	TUNER 6	6
AUX	AUX	AUX - HDD 7	7
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
+ VOL	Vol+	+ VOL	Vol+
VOL –	Vol-	VOL –	Vol-
TONE/BAL	Tone/BAL	OK	OK
L/–	L/-		Left
R/+	R/+		Right
DIRECT	Direct	LIST SMART	Smart / List

Original	Replacement

https://telecommandes-mandis.be/en/Pioneer/1065099-21374-replacement-remote-control-for-Pioneer-8300747200010-AXD7472.html