Original		Replacement	
STANDBY	Standby	Power	
USB/CARD	USB/Card	SHIFT + USB 8	Shift + 8
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
0/10	0/10	HDMI - SAT 0	0

Original		Replacement	
MENU	Menu	HOME MENU	Menu / Home
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
DISPLAY	Display	MEDIA DISPLAY	Display / Media
TITLE	Title	TITLE SOUND	Sound / Title
◀	Left	◀	Left
▲	Up	▲	Up
▶	Right	▶	Right
ENTER	Enter	OK	OK
▼	Down	▼	Down
REV	<<	TUNE-	<< / Tune-
FWD	>>	TUNE+	>> / Tune+
PREV	I<<	PRESET-	I<< / Preset-
NEXT	>>I	PRESET+	>>I / Preset+
STEP	Step	STEP - FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
PLAY/PAUSE	Play/Pause	SLOW	Play / Slow
VOL +	Vol+	VOL +	Vol+

Original	Replacement	Original	Replacement
REPEAT Repeat	APP REPEAT Green / APP / Repeat		
A-B A-B	YouTube REPEAT A-B Yellow / YouTube / Repeat		
ANGLE Angle	ANGLE INFO Info / Angle		
MUTE Mute	DIMMER MUTE Mute / Dimmer		
– Vol-	VOL – Vol-		
L/R L/R	RDS AV INPUT AV / Input / RDS		
N/P N/P	GOTO TEXT Text / Goto		
PBC PBC	LIST SMART Smart / List		
SLOW Slow	SHIFT + SLOW ▶ Shift + Play /		
V-MODE V-Mode	TOP MENU D.MENU D.Menu / Top		
RETURN Return	RETURN BACK Back / Return		
HD/Res. HD/Res.	FORMAT PICTURE Picture / Format		
PROGRAM Program	PROGRAM TV/ RADIO TV/Radio /		
ZOOM Zoom	SIZE ZOOM Zoom / Size		