Mandis shop

RM-SUXVJ3-WJ

Original		Replacement	
	Power		Power
DISPLAY	Display	MEDIA DISPLAY	Display / Media
iPad	Play/Pause iPa	SLOW	Play / Slow
iPod	Play/Pause iPo	STEP-FREEZE	Pause / Step / Freeze
TUNER	Tuner	TUNER 6	6
PC	PC	PC FAV MARKER	Fav / Marker / PC
AUDIO IN	Audio In	LANG I/II AUDIO	Audio / Lang I/II
MENU	Menu	HOME MENU	Menu / Home
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
UP	Up		Up
DOWN	Down		Down
I<<	I<< / Preset-	PRESET-	I<< / Preset-
>>I	>>I / Preset+	PRESET+	>>I / Preset+
SET	Set	OK	OK
	Stop	HOLD	Stop / Hold
<<	<< / Tune-	TUNE-	<< / Tune-
>>	>> / Tune+	TUNE+	>> / Tune+

Original		Replacement	
PROGRAM	Program	PROGRAM TV/RADIO	TV/Radio /
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random
TUNER MODE REPEAT	Repeat/Tuner	GOTO TEXT	Text / Goto
CLOCK/TIMER	Clock/Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
APS	APS	SIZE ZOOM	Zoom / Size
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
VOLUME +	Vol +	VOL +	Vol +
VOLUME −	Vol -	VOL −	Vol -
SOUND TURBO	Sound Turbo	SHIFT + PROGRAM TV/RADIO	Shift + TV/Radio / Program
HBS	HBS	TOP MENU D.MENU	D.Menu / Top
SOUND MODE	Sound Mode	TITLE SOUND	Sound / Title
SURROUND	Surround	SURROUND	Eject / Surround
RESUME	Resume	FORMAT PICTURE	Picture / Format
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer

https://telecomandes.com/JVC-1650-756-replacement-remote-control-for-JVC-RM-SUXVJ3-WJ.htm