| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | e/Energy Saving | SHIFT + OK | Shift + OK |
| | AV Mode | GOTO TEXT | Text / Goto |
| | Input | RDS AV INPUT | AV / Input / RDS |
| | TV | PROGRAM TV/ RADIO | TV/Radio / |
| | 1 | TV 1 | 1 |
| | 2 | DVD 2 | 2 |
| | 3 | CD - STB 3 | 3 |
| | 4 | VIDEO 4 | 4 |
| | 5 | TAPE 5 | 5 |
| | 6 | TUNER 6 | 6 |
| | 7 | AUX - HDD 7 | 7 |
| | 8 | USB 8 | 8 |
| | 9 | BLUETOOTH 9 | 9 |
| | 0 | HDMI - SAT 0 | 0 |
| | List | LIST SMART | Smart / List |
| | Q.View | OPT-TOOLS SETUP | Setup / OPT / Tools |

| Original | | Replacement | |
|---|---|---|---|
| | FAV/Mark | PC FAV MARKER | Fav / Marker / PC |
| | Ratio | FORMAT PICTURE | Picture / Format |
| | Mute/Delete | DIMMER MUTE | Mute / Dimmer |
| | Vol+ | VOL + | Vol+ |
| | Vol- | VOL − | Vol- |
| | CH+ | CH PAGE + | CH+ / Page+ |
| | CH- | CH PAGE − | CH- / Page- |
| | Menu | HOME MENU | Menu / Home |
| | Netcast | MEDIA DISPLAY | Display / Media |
| | Q.Menu | TOP MENU D.MENU | D.Menu / Top |
| | Up | | Up |
| | Down | | Down |
| | Left | | Left |
| | Right | | Right |
| | Enter | OK | OK |
| | Back | RETURN BACK | Back / Return |
| | Simplink | SIZE ZOOM | Zoom / Size |

| Original | | Replacement | |
|---|---|---|---|
| EXIT | Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| | Red | NETFLIX SEARCH | Red / Netflix / Search |
| | Green | APP REPEAT | Green / APP / Repeat |
| | Yellow | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| | Blue | Prime Video RANDOM | Blue / Prime Video / Random |
| ■ | Stop | HOLD ■ | Stop / Hold |
| ▶ | Play | SLOW ▶ | Play / Slow |
| ❚❚ | Pause | STEP - FREEZE ❚❚ | Pause / Step / Freeze |
| ◀◀ | << | TUNE- ◀◀ | << / Tune- |
| ▶▶ | >> | TUNE+ ▶▶ | >> / Tune+ |

| Original | Replacement |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |