Original		Replacement	
	Power		Power
	e/Energy Saving	SHIFT + OK	Shift + OK
	AV Mode	GOTO TEXT	Text / Goto
	Input	RDS AV INPUT	AV / Input / RDS
	TV	PROGRAM TV/ RADIO	TV/Radio /
	1	TV 1	1
	2	DVD 2	2
	3	CD - STB 3	3
	4	VIDEO 4	4
	5	TAPE 5	5
	6	TUNER 6	6
	7	AUX - HDD 7	7
	8	USB 8	8
	9	BLUETOOTH 9	9
	0	HDMI - SAT 0	0
	List	LIST SMART	Smart / List
	Q.View	OPT-TOOLS SETUP	Setup / OPT / Tools

Original		Replacement	
	FAV/Mark	PC FAV MARKER	Fav / Marker / PC
	Ratio	FORMAT PICTURE	Picture / Format
	Mute/Delete	DIMMER MUTE	Mute / Dimmer
	Vol+	VOL +	Vol+
	Vol-	VOL −	Vol-
	CH+	CH PAGE +	CH+ / Page+
	CH-	CH PAGE −	CH- / Page-
	Menu	HOME MENU	Menu / Home
	Netcast	MEDIA DISPLAY	Display / Media
	Q.Menu	TOP MENU D.MENU	D.Menu / Top
	Up		Up
	Down		Down
	Left		Left
	Right		Right
	Enter	OK	OK
	Back	RETURN BACK	Back / Return
	Simplink	SIZE ZOOM	Zoom / Size

Original		Replacement	
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
■	Stop	HOLD ■	Stop / Hold
▶	Play	SLOW ▶	Play / Slow
❚❚	Pause	STEP - FREEZE ❚❚	Pause / Step / Freeze
◀◀	<<	TUNE- ◀◀	<< / Tune-
▶▶	>>	TUNE+ ▶▶	>> / Tune+

Original	Replacement