Mandis shop

Yamaha WQ455200

Original		Replacement	
ON/OFF	On/Off		Power
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
iPod	iPod	PC FAV MARKER	Fav / Marker / PC
FM	FM	TUNER 6	6
AUX	AUX	AUX - HDD 7	7
< PRESET	< Preset		Left
PRESET >	Preset >		Right
<< TUNING	<<Tuning	TUNE-	<< / Tune-
TUNING >>	Tuning >>	TUNE+	>> / Tune+
MEMORY	Memory FM	LIST SMART	Smart / List
CLOCK	Clock/Set	TOP MENU D.MENU	D.Menu / Top
FUNCTION	Function	OPT-TOOLS SETUP	Setup / OPT /
MENU	Menu	HOME MENU	Menu / Home
▲	▲	CH PAGE +	CH+ / Page+
I<<	I<<	PRESET-	I<< / Preset-
	Ok	OK	OK
>>I	>>I	PRESET+	>>I / Preset+

Original		Replacement	
DISPLAY	Display	MEDIA DISPLAY	Display / Media
►II	Play	SLOW	Play / Slow
►II	Pause	STEP - FREEZE	Pause / Step / Freeze
▼	▼	CH PAGE −	CH- / Page-
DSP	DSP	RDS AV INPUT	AV / Input / RDS
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
	Vol-	VOL −	Vol-
	Vol+	VOL +	Vol+

https://telecommandes-mandis.be/en/Yamaha/1066067-82913-replacement-remote-control-for-Yamaha-TSX-120-WQ455200.html