Mandis shop

RM-V730U

Original		Replacement	
T ZOOM	Zoom T	CH+ PAGE	CH+ / Page+
START/STOP	Star/Stop		Power
ZOOM W	Zoom W	CH- PAGE	CH- / Page-
SNAPSHOT	Snapshot	FORMAT PICTURE	Picture / Format
INFO	Info	ANGLE INFO	Info / Angle
-	-	VOL -	Vol -
Up	Up		Up
+	+	+ VOL	Vol +
<<	<<	TUNE-	<< / Tune-
Left	Left		Left
SET	SET	OPT-TOOLS SETUP	Setup / OPT /
Play	Play	SLOW	Play / Slow
Pause	Pause	STEP-FREEZE	Pause / Step / Freeze
Right	Right		Right
>>	>>	TUNE+	>> / Tune+
I <<	I <<	PRESET-	I << / Preset-
Down	Down		Down

Original		Replacement	
>>I	>>I	PRESET+	>>I / Preset+
PLAYLIST	Playlist	MEDIA DISPLAY	Display / Media
DATE	Date	TIMER SLEEP	Sleep / Timer
INDEX	Index	LIST SMART	Smart / List

https://telecomands.mandis.be/JVC/1657-853-replacement-remote-control-for-JVC-RM-V730U.htm