Original		Replacement	
VCR	Power VCR		Power
TV	Power Tv	SHIFT +	Shift + Power
REPLAY	Replay	Prime Video / RANDOM	Blue / Prime Video / Random
OSD/DISPLAY	OSD/Display	MEDIA / DISPLAY	Display / Media
EXIT	Exit	CLEAR / EXIT / CANCEL	Exit / Cancel / Clear
AV LINK	AV Link	RDS / AV INPUT	AV / Input / RDS
AUDIO	Audio	LANG I/II / AUDIO	Audio / Lang I/II
SEARCH	Search	NETFLIX / SEARCH	Red / Netflix / Search
REC	Rec	REC MODE	Rec / Rec Mode
INDEX	Index >>I	PRESET+	>>I / Preset+
INDEX	I<< Index	PRESET-	I<< / Preset-
TRACKING/V-LOCK	Tracking-V-Lock	CH PAGE +	CH+ / Page+
	Tracking-V-Lock Down	CH PAGE −	CH- / Page-
AV	AV Tv	SHIFT +	RDS / AV INPUT — Shift + AV / Input / RDS
VOLUME	Volume+ Tv	VOL +	Vol+
	Volume- Tv	VOL −	Vol-
	CH+ Tv	SHIFT +	CH PAGE + — Shift + CH+ / Page+

Original		Replacement	
	CH- Tv	SHIFT +	CH PAGE − — Shift + CH- /
MENU	Menu	HOME / MENU	Menu / Home
INPUT	Input	LIST / SMART	Smart / List
RESET	Reset	RETURN / BACK	Back / Return
II/▶	Pause/Step	STEP-FREEZE II	Pause / Step / Freeze
OK	OK	OK	OK
	Stop	HOLD ■	Stop / Hold
	Down	▼	Down
	Play	SLOW ▶	Play / Slow
	Up	▲	Up
	Right	▶	Right
	>>	TUNE+ ▶▶	>> / Tune+
	<<	TUNE- ◀◀	<< / Tune-
	Left	◀	Left
PROG./CHECK	Prog/Check	PROGRAM / TV/RADIO	TV/Radio /
CANCEL	Cancel	SHIFT +	CLEAR / EXIT / CANCEL — Shift + Exit / Cancel / Clear
SP/LP/EP	SP/LP/EP	FORMAT / PICTURE	Picture / Format

Original	Replacement
Timer	Sleep / Timer
Prog/Check Up	Shift + Up
Prog/Check	Shift + Down
Date+	1
Date-	4
On+	2
On-	5
Off+	3
Off-	6

Original	Replacement