Original		Replacement	
Standby		Power	
Subtitle		Subtitle / EQ	
Audio		Audio / Lang I/II	
Mute		Mute / Dimmer	
<<		<< / Tune-	
Play / Pause		Play / Slow	
Play / Pause		Pause / Step / Freeze	
I<<		I<< / Preset-	
>>		>> / Tune+	
Stop		Stop / Hold	
>>I		>>I / Preset+	
Menu		Menu / Home	
Up / CH+		Up	
Up / CH+		CH+ / Page+	
Exit		Exit / Cancel / Clear	
Left / Vol-		Left	
Left / Vol-		Vol-	

Original		Replacement	
OK		OK	
Right / Vol+		Vol+	
Right / Vol+		Right	
Record		Rec / Rec Mode	
Down / CH-		CH- / Page-	
Down / CH-		Down	
Timeshift		Sleep / Timer	
1		1	
2		2	
3		3	
--		Guide / EPG / -/--	
4		4	
5		5	
6		6	
Recall		Back / Return	
7		7	
8		8	

Original		Replacement		Original	Replacement
9	9	BLUETOOTH 9	9		
0	0	HDMI - SAT 0	0		
FAV	--	PC FAV MARKER	Fav / Marker / PC		
DEVICE	Device	LIST SMART	Smart / List		
FILE	File	MEDIA DISPLAY	Display / Media		
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /		
TELETEXT	Teletext	GOTO TEXT	Text / Goto		
DIGEST	Mosaic	FORMAT PICTURE	Picture / Format		
TV/RADIO	TV/Radio	PROGRAM TV/ RADIO	TV/Radio /		
INFO	Info	ANGLE INFO	Info / Angle		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		