Mandis shop

RC- 217

Original		Replacement	
PLAY	Play	SLOW	Play / Slow
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I <<	PRESET-	I << / Preset-
	>>I	PRESET+	>>I / Preset+
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
AUTO EDIT	Auto Edit	SIZE ZOOM	Zoom / Size
TIME	Time	TIMER SLEEP	Sleep / Timer
PROGRAM	Program	PROGRAM TV/RADIO	TV/Radio /
AUTO SPACE	Auto Space	GOTO TEXT	Text / Goto
INDEX	Index	ANGLE INFO	Info / Angle
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
VOLUME	Volume+	+ VOL	Vol +
DIRECT	Direct	LIST SMART	Smart / List
VOLUME	Volume-	VOL −	Vol -

Original		Replacement	
DISPLAY	Display	MEDIA DISPLAY	Display / Media
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
10	10	HDMI-SAT 0	0
CALL	Call	PC FAV MARKER	Fav / Marker / PC
ALL	Repeat All	NETFLIX SEARCH	Red / Netflix / Search
REPEAT(1)	Repeat (1)	APP REPEAT	Green / APP / Repeat
A-B	Repeat A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random

https://telecomands.nl/denon/1625/254-replacement-remote-control-for-denon-rc-217.html