Original		Replacement	
	Mute	MUTE	Mute
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
i	i	DISPLAY INFO	Info
0	0	0	0
AV	AV	TIMER AV	AV
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow

Original		Replacement	
	Blue	D	Blue
TV/DTV	Tv/DTV	HOME SMART	Smart
	Up		Up
MENU	Menu	TOP MENU MENU	Menu
	Left		Left
OK	OK	OK	Ok
	Right		Right
	[≡] / Text	REPEAT TEXT	Text
	Down		Down
BACK	Back	RETURN BACK	Back
P	P+	+ CH	Ch +
	Vol +	+ VOL	Vol +
P	P-	CH −	Ch -
	Vol -	VOL −	Vol -
	^ / Hold	PICTURE FORMAT	Format
F.T/L	<< / F.T/L	<<	<<
TV/RADIO	Play / Tv/Radio [?]	SEARCH TV/R	TV/R

Original	Replacement	Original	Replacement
Play / Tv/Radio [?]	PLAY MODE ▶ Play		
>> / Guide / Siz	GUIDE Guide		
>> / Guide / Siz	>> >>		
v / Timer / Boo	ECO 3D 3D		
Rec / Top Menu	SHIFT + TOP MENU MENU Shift + Menu		
Rec / Top Menu	REC MODE Rec		
Stop / I-II / [	■ Stop		
Stop / I-II / [	SOUND DUAL Dual		
Pause / [...] /	AD SUBT Subt		
Pause / [...] /	❚❚ Pause		
ZOOM	ZOOM ⏏ Eject		
(↔)	FAV PRE-CH Pre Ch		

Original	Replacement	Original	Replacement
Power	Power		
Up	Up		
Menu	Menu		
Left	Left		
OK	Ok		
Right	Right		
Down	Down		
Back	Back		
↑	Ch +		
<< / F.T/L	<<		
Play / Tv/Radio [?]	Play		
>> / Guide / Siz	>>		
↓	Ch -		
Rec/Top Menu	Rec		
Stop / I-II / [	Stop		
Pause / [...] /	Pause		

Original		Replacement		Original	Replacement
	Power		Power		
	Up		Up		
	Down		Down		
	<<		<<		
	Pl ay		Pl ay		
	>>		>>		
	Rec		Rec		
	St op		St op		
	Pause		Pause		