Original	Replacement	Original	Replacement
Standby	Power	Source	AV
DTV/VCR	Smart	Tv/Radio	TV/R
Text	Text	CH+	Ch +
Vol +	Vol +	CH-	Ch -
Vol -	Vol -	Up	Up
Mute	Mute	Down	Down
Info	Info	Right / FAV+	Right
EPG	Guide	Left / FAV-	Left
Play	Play	Enter	Ok
Pause	Pause	1	1
Stop	Stop	2	2
<<	<<	3	3
>>	>>	4	4
I <<	I <<	5	5
>>I	>>I	6	6
Setup	Menu	7	7
Exit	Exit	8	8

Original		Replacement		Original	Replacement
9	9	9	9		
0	0	0	0		
RECALL	Recall	RETURN BACK	Back		
GOTO	Goto	ECO 3D	3D		
FAVORITE	Favorite	FAV PRE-CH	Pre Ch		
MODE	Mode	APP MEDIA	Media		
AUDIO	Audio	SHIFT +	SOUND DUAL	Shift + Dual	
LANGUAGE	Language	SOUND DUAL	Dual		
REPEAT	Red/ Repeat	A	Red		
A-B	Green/ A-B	B	Green		
ZOOM	Yellow/ Zoom	C	Yellow		
SUBTITLE	Blue/ Subtitle	D	Blue		