Original		Replacement	
STANDBY	Standby		Power
OPEN/CLOSE	Open/Close	ZOOM	Eject
SUBTITLE	Subtitle	AD SUBT	Subt
AUDIO	Audio	SOUND DUAL	Dual
ANGLE	Angle	ECO 3D	3D
TIME	Time	E-MANUAL D.MENU	D. Menu
SETUP	Setup	SETTINGS OPT	Options
STOP	Stop		Stop
PLAY	Play	PLAY MODE	Play
SOURCE	Source	TIMER AV	AV
RECORD	Record	REC MODE	Rec
PAUSE	Pause		Pause
FBW	FBW		<<
FFW	FFW		>>
PREV	Prev		I<<
SLOW	Slow	SHIFT + PLAY MODE	Shift + Play
NEXT	Next		>>I

Original		Replacement	
DV	DV	HOME SMART	Smart
RETURN	Return	RETURN BACK	Back
ADD/CLEAR	ADD/Clear	CLEAR EXIT	Exit
GOTO	GOTO	FAV PRE-CH	Pre Ch
	Up		Up
	Down		Down
EDIT	Edit	A	Red
	Left		Left
	Right		Right
ENTER	Enter	OK	Ok
DISCFUNC	Discfunc	-/-- GUIDE	Guide
SHUFFLE	Shuffle	SEARCH TV/R	TV/R
PROGRAM	Program	PROG SLEEP	Sleep
REPEAT	Repeat	REPEAT TEXT	Text
ZOOM	Zoom	SHIFT + ZOOM	Shift + Eject
USB	USB	APP MEDIA	Media
TIMER	Timer	SHIFT + TIMER AV	Shift + AV

Original		Replacement	
CHAN −	Channel -	CH −	Ch -
ANNEL +	Channel +	+ CH	Ch +
NTSC/PAL	NTSC/PAL	PICTURE FORMAT	Format
DISPLAY	Display	DISPLAY INFO	Info
VOLL −	Volume-	VOL −	Vol -
LUME +	Volume+	+ VOL	Vol +
TITLE	Title	DISC NAV LIST	List
MENU	Menu	TOP MENU MENU	Menu
MUTE	Mute	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8

Original		Replacement	
9	9	9	9
0	0	0	0
A-B	A-B	SHIFT + REPEAT TEXT	Shift + Text