Original		Replacement	
Power		Power	
Mute		Mute / Dimmer	
DTV		Smart / List	
Radio		TV/Radio /	
USB		Shift + 8	
DVD		Shift + 2	
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	
0		0	
Tv Guide		Guide / EPG / -/--	

Original		Replacement	
Recall		Back / Return	
P.Mode		Picture / Format	
S.Mode		Sound / Title	
FAV		Fav / Marker / PC	
Vol+		Vol+	
Vol-		Vol-	
CH+		CH+ / Page+	
CH-		CH- / Page-	
Menu		Menu / Home	
Exit		Exit / Cancel / Clear	
Source		AV / Input / RDS	
Info		Info / Angle	
Up		Up	
Down		Down	
Left		Left	
Right		Right	
OK		OK	

Original		Replacement	
ASPECT	Aspect	SHIFT + FORMAT PICTURE	Shift + Picture / Format
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
TEXT	Text	GOTO TEXT	Text / Goto
TEXT HOLD	Text Hold	OPT-TOOLS SETUP	Setup / OPT /
TEXT/DVD ZOOM	Zoom/Text/DVD	SIZE ZOOM	Zoom / Size
DISPLAY	Power/Display	MEDIA DISPLAY	Display / Media
DVD MENU	Rec	REC MODE	Rec / Rec Mode
DVD MENU	DVD Menu	TOP MENU D.MENU	D.Menu / Top
⏮	I<<	PRESET- ⏮	I<< / Preset-
⏭	>>I	PRESET+ ⏭	>>I / Preset+
■/⏏	Stop/Eject	HOLD ■	Stop / Hold
DVD SETUP REC LIST	Rec List/DVD	SHIFT + REC MODE	Shift + Rec / Rec Mode
◀◀	<< PVR/DVD	TUNE- ◀◀	<< / Tune-
▶▶	>> PVR/DVD	TUNE+ ▶▶	>> / Tune+
⏯	Play	SLOW ▶	Play / Slow

Original		Replacement	
⏯	Pause	STEP-FREEZE ⏸	Pause / Step / Freeze
GOTO	Red/Goto	NETFLIX SEARCH	Red / Netflix / Search
A-B	Green/A-B	APP REPEAT	Green / APP / Repeat
ANGLE 3D	Yellow/Angle/3D	YouTube REPEAT A-B	Yellow / YouTube / Repeat
REPEAT	Blue/Repeat	Prime Video RANDOM	Blue / Prime Video / Random