Mandis shop

# Denon RC-824

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| TUNING UP | Tuning Up | + CH | Ch + |
| DOWN | Tuning Down | CH − | Ch - |
| | No name | CLEAR EXIT | Exit |
| SEARCH/ CHARACTER | Search/Character | SEARCH TV/R | TV/R |
| DISPLAY | Display | DISPLAY INFO | Info |
| SHIFT/PTY | Shift/PTY | SETTINGS OPT | Options |
| MEMORY | Memory | APP MEDIA | Media |
| AUTO/ MANU | Auto/Manu | RETURN BACK | Back |

| Original | | Replacement | |
|---|---|---|---|
| BAND | Band | HOME SMART | Smart |