Original		Replacement	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
FAV	FAV	FAV MARKER	Fav / Marker / PC
0	0	0	0
TXT	TXT	GOTO TEXT	Text / Goto
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random

Original		Replacement	
CEC	CEC	SMART	Smart / List
?	?	D.MENU	D.Menu / Top
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
BACK	Back	RETURN BACK	Back / Return
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
TOOLS	Tools	OPT-TOOLS SETUP	Setup / OPT /
	Vol +	VOL	Vol +
	Source	RDS AV INPUT	AV / Input / RDS
P	PR+	CH PAGE	CH+ / Page+
	Vol -	VOL	Vol -
	Mute	DIMMER MUTE	Mute / Dimmer

Original		Replacement		Original		Replacement	
P −	PR-	CH PAGE −	CH- / Page-				
⏮	I <	PRESET- ⏮	I << / Preset-				
⏭	>I	PRESET+ ⏭	>>I / Preset+				
⏪	<<	TUNE- ⏪	<< / Tune-				
⏩	>>	TUNE+ ⏩	>> / Tune+				
●	Rec	REC MODE ●	Rec / Rec Mode				
▶	Play	SLOW ▶	Play / Slow				
⏸	Pause	STEP·FREEZE ⏸	Pause / Step / Freeze				
■	Stop	HOLD ■	Stop / Hold				
◁▷	[<>]	FORMAT PICTURE	Picture / Format				
💬	Dialog	LANG I/II AUDIO	Audio / Lang I/II				
▭	[...]	EQ SUBTITLE	Subtitle / EQ				
TV/Radio	Tv/Radio	PROGRAM TV/RADIO	TV/Radio /				
My Media	My Media	MEDIA DISPLAY	Display / Media				